

SLVRS Decontamination Procedures

3/31/2020

If suspected or known Corona Virus patient has been in one of SLVRS trucks follow this procedure to DECON the truck.

- 1. At hospital: bring patient to room 10, EMT gives report, Driver or second EMT stays in gloves, gown and mask and returns to truck immediately.**
- 2. Use oxivir wipes to decon, anything that touched the patient. Pay special attention to the BP cuff, stethoscope, glucometer and thermometer and monitor.**
- 3. Now wipe down all flat counter and bench surfaces, oxygen tanks, microphone for the radio, door knobs, (inside and out) Stair chair if used. etc.**
- 4. When done carefully remove PPE (per protocol) and discard in outside garbage.**
- 5. Leave items out to air dry and return to base. Once at base**
- 6. Leave truck outside with door open for two hours. This will ensure adequate air exchange in the truck.**
- 7. After 2 hours, fill and turn on the steamer. Steam the entire truck starting from the front and working to the back. (steamer takes a while to warm up, when light turns green it is good to go.)**
- 8. You should only need to do the back unless the driver feels they have contaminated the front of the truck.**
- 9. Call truck back in service.**

FYI: We are working on getting a UVC light to use but it is back ordered.

We just ordered a fogger which can also be used with a hydrogen peroxide based solution to Decon the truck. Sooo Policy may change but we wanted to ensure everyone was on the same page and the trucks are getting adequately cleaned.

The steamer, UVC light and the fogger can also be used to decon the office, day room, and apartments.

Thank you for your compliance with this cleaning policy. Your co-workers do appreciate this.